



Accessoires de cuisine en verre



TAS 1161 V VERRE
Ø 15



TAS 1164 V VERRE
Ø 22,5



TAS 1166 V VERRE
Ø 29

TAS 1162 V Ø 18

TAS 1165 V Ø 25



CPL 1771 V VERRE
14,5 x 14,5

CPL 1772 V 20 x 20



CPL 1773 V 25 x 25

CCP 1230 V VERRE DÉPOLI
30 x 15 x 2



CCP 1220 V VERRE DÉPOLI
Ø 28 H 2,5



CSP 1250 V VERRE
Ø 23 H 26



CSP 1240 V VERRE
Ø 19 H 27



CSP 1270 V VERRE
Ø 23 H 26



TCL 136 SV VERRE
Cloches avec gravure « Pâtissier »
Ø 16 H 13
→ Ø 28 H 26

s/3



CSP 1300 V VERRE
Ø 25 H 11,5